



Manufacturers and distributors of quality chassis, suspension, driveline and components

## DUAL MASTER CYLINDER MOUNT

Part # 3904 Part list;

- 2...Roll bar gussets
- 1...Mopar master cylinder mount bracket
- 1...Find the best location for the master cylinder on the frame rail away from the heat of the headers. Make sure you can get to the caps and brake lines easily. Mount the master cylinder first before you mount the pedal.
- 2...Bolt the master cylinder to the bracket. Hold the master cylinder in the predetermined location and make sure the brake rod is straight with the pedal. Also make sure you have enough ground clearance.
- 3...Tack the bracket to the chassis. Tack the roll bar gusset to the bracket and the chassis. The top gusset goes to the front and the bottom gusset goes to the rear.
- 4...Remove the master cylinder and weld all the brackets to the chassis.