



Manufacturers and Distributors of quality chassis, suspension, driveline and components

Tech Line & Information: (561) 863-2188

Orders Only: (800) 327-9402

Fax: (561) 863-1424

## C/E 4111 - RADIATOR MOUNT KIT

### **PARTS LIST:**

- 2... RADIATOR MOUNT UPRIGHTS    2... HAIR PIN CLIPS  
2... WELD MOUNT SLEEVES

These instructions are just one way of properly installing Radiator Mount kits. Depending on your fabrication experience, you may find it easier or more convenient using other methods that accomplish the same results. Every installation is slightly different and we have attempted to structure these instructions to make your installation as easy as possible.

### **Installation:**

- 1... Bolt the radiator mounts to the radiator. (Customer must supply bolts)
- 2... Position the radiator in the car to the correct height/location. Cut the radiator mounts to lower the radiator if needed.
- 3... Slide the weld mounting sleeves onto the radiator mounts half way. Hold the radiator in place and tack weld the sleeves to the frame or appropriate support. Remove the radiator and weld the sleeves into place.
- 4... Install radiator with the mounts. Drill 1/8" hole through the bottom of both mounting sleeves and install the 1/8" Hair pin clips to secure the radiator into place.

