



3/8" long bolts go in the wing

1/2" long bolts go in the hinges

8017

