



Manufacturers and Distributors of quality chassis, suspension, driveline and components

Tech Line & Information: (561) 863-2188

Orders Only: (800) 327-9402

Fax: (561) 863-1424

## C/E4710 – Ground Stud Kit

### Parts list:

5... C/E 4710-1	Ground Studs
5... ABT 1020	1/4" Flat Washer
5... ABT 1110	1/4" Nylock Nut

These instructions are just one way of properly installing Ground Stud Kits. Depending on your fabrication experience, you may find it easier or more convenient using other methods that accomplish the same results. Every installation is slightly different and we have attempted to structure these instructions to make your installation as easy as possible.

NOTE: Welding is required.

1...Determine the best location for the stud to be placed. Typically as close to grounded part as possible. Drill a 1/4" hole.

2...Insert the stud in the hole and weld in place. Make sure to protect the threads from any weld splatter or paint.

