



Tech Line & Information: (561) 863-2188
Orders Only: (800) 327-9402
Fax: (561) 863-1424

Manufacturers and Distributors of quality chassis,
suspension, driveline and components

C/E 4118 - BODY MOUNT KIT

PARTS LIST:

8...Light Weight Mount Plate 12'...7/16" x .058" Tubing 4'...5/16" x .058" Tubing

These instructions are just one way of properly installing body mount kits. Depending on your fabrication experience, you may find it easier or more convenient using other methods that accomplish the same results. Every installation is slightly different and we have attempted to structure these instructions to make your installation as easy as possible.

1...Use four of the flat mounting plates and the four pieces of 5/16" tubing to attach the roof section of the car to the top of the roll cage. The flat mounting plates are welded on steel panels. Use pop rivets on fiberglass panels to hold in place until finished. Remove the rivets when finished placing the body panel and the plates are fiberglassed into place.

2...The last four flat mounting plates and the 7/16" tubing are used to mount the rear quarter panels to the chassis. Mount one plate high up on the quarter panel to support the weight and one low to keep it from moving in and out. Use two pieces of tubing on each of the top mounting plates to form a triangle (added strength). Use at least one piece of tubing on each of the bottom plates.

