



Manufacturers and Distributors of quality chassis, suspension, driveline and components

Tech Line & Information: (561) 863-2188

Orders Only: (800) 327-9402

Fax: (561) 863-1424

## Single Nitrous Bottle Mount

(10 lbs. Bottle)

### C/E 5501

#### Parts List:

1...Bottle Base Plate	1...Lower Bottle Ring	1...Top 1/2 Ring Plate
1...Hold Down Ring	4...Base Sleeves	3...10lbs. Mounting Rods
2...Threaded Knobs	2...Top Mounting Hex Studs	3...3/8" X 1-3/4" Bolts
1...3/8" X 1" Bolts	2... 7/16" Washers	1...1/4" X 1-1/2" Bolt
1...1/4" Nylock Nut	1...Edge Guard (cut to fit)	

1...Bolt the Bottle Base Plate and the Lower Bottle Ring to the Mounting Rods using the Base Sleeves, bolts and washers (3-3/8" and 1 -1/4"). Slide the bolts through the Bottom Base Plate then through the 1" Base Sleeves then through the Lower Ring and thread into the Mounting Rods. It is suggested to use blue lock tight on these threads.

2...Next slip the 2 Top Mounting Hex Studs through the outer holes of the Top 1/2 Ring Plate with the washers and thread into the top of the outer Mounting Rods. It is suggested to use blue lock tight on these threads.

3...In the remaining bolt hole use the 1" X 3/8" bolt.

4...The top hold down ring is held on with the two threaded knobs.

5...Cut the edge guard to length and place on the bottom ring and the Top 1/2 Ring Plate. Contact cement will aid in holding the edge guard in place.

5...The bottle mount can be bolted to the floor or mounting tabs with 3/8" bolts supplied by the customer.

6...If you would like the bottle mount to be welded in place. The mounting brackets or the mounting tubes that go to the chassis can be welded to the mounting rods or any of the flat plates.

